PSC NY No. 11--COMMUNICATIONS

Verizon New York Inc.

Section 6 Original Page 24

ACCESS SERVICE

6. <u>SWITCHED ACCESS SERVICE</u> (Cont'd)

6.1 General (Cont'd)

6.1.2 Rate Categories (Cont'd)

(A) Local Transport (Cont'd)

(1) <u>Interface Groups</u> (Cont'd)

(g) Glossary of Premises Interface Codes (Cont'd)

<u>Code</u>	<u>Option</u>	<u>Definition</u>
GS-		ground start loop signaling – closed end function by customer or customer's end user.
LS-		loop start loop signaling - closed end function by customer or customer's end user.
RV-	0	reverse battery signaling, one way operation, originate by customer.
-	T	reverse battery signaling, one way operation, terminate function by customer or customer's end user.
SF-		single frequency signaling with VF band at either customer POT or customer's end user POT.

(h) Impedance

The nominal reference impedance with which the channel will be terminated for the purpose of evaluating transmission performance:

Code(s)
2
3
5
6
9

Issued: August 1, 2001 Effective: September 1, 2001